

Product Label - Operable Windows

➔ JT WINDOWS ←

IMPORTANT – PLEASE READ PRIOR TO INSTALLATION

BEFORE PRODUCT INSTALLATION

- CHECK FOR CORRECT SIZE.
- CHECK FOR ANY FLAWS IN MATERIAL OR QUALITY OF WORKMANSHIP. IF ANY PROBLEMS ARISE, **DO NOT INSTALL OR PREFINISH. CALL AND RETURN PRODUCT TO SUPPLIER.**
- FAILURE TO DO SO WILL VOID ANY RETURN OR EXCHANGE.
- **INSTALLING OR PREFINISHING UNIT IMPLIES ACCEPTANCE.**

FINISHING

- HANDLE WITH CARE AT ALL TIMES. DO NOT EXPOSE TO WEATHER OR EXTREME TEMPERATURES PRIOR TO FINISHING.
- REMOVE EXCESS GLAZING MATERIAL WITH A SHARP PUTTY OR X-ACTO KNIFE.
- PRIME AND PAINT **ALL 6 SURFACES** WITH A MINIMUM OF AT LEAST 2 COATINGS EACH.
- BE SURE TO OVERLAP PAINT 1/16" ONTO GLASS – REFER TO ***JT FINISHING INSTRUCTIONS*** SHEET.
- **CAUTION: PRIMER IS NOT A FINISH COAT AND WILL NOT STAND UP TO WEATHER. IT IS PART OF THE PREPARATION PROCESS FOR FINISH COATING.**
- **STAINS AND CLEAR FINISHES, AND DARK COLORS, ARE NOT RECOMMENDED FOR EXTERIOR USAGE AS THEY WEATHER RAPIDLY AND PROVIDE POOR WOOD PROTECTION.**

CAUTION: USE EXTERIOR PAINTS FOR EXTERIOR PAINTING ONLY. PAINT MUST OVERLAP PUTTY OR WOOD STOP 1/16" ON TO GLASS TO FORM A PROPER SEAL AGAINST MOISTURE. DO NOT PAINT WEATHER STRIPPING.

WE DO NOT TAKE RESPONSIBILITY FOR THE STAINABILITY OF ANY PRODUCT YOU MAY PURCHASE.

AT JT WINDOWS INC. EXTREME CARE IS TAKEN IN PRODUCING HIGH QUALITY, WEATHER TIGHT UNITS. ALL EXTERIOR JOINTS ARE TIGHTLY FIT AND FILLED AS NECESSARY TO ASSURE WEATHERABILITY. SINCE ALL WINDOWS LEAVE OUR FACTORY UNFINISHED, AND THE FINAL WEATHER COATINGS (FINISHING) ULTIMATELY REST IN THE HANDS OF OUR CUSTOMERS, **IT IS IMPOSSIBLE FOR THE FACTORY TO WARRANT AGAINST LEAKAGE.**

WE SUGGEST: AFTER THE FIRST 3-12 MONTHS INSPECT ALL WINDOW JOINTS FOR CRACKS OR SEPARATION IN FINISH. IF ANY ARE FOUND, LIGHTLY SAND AND FILL WITH CAULKING, THEN REPAINT.

WWW.JTWINDOWS.COM

INSTALLATION INSTRUCTIONS

- 1) TO ASSURE PROPER OPERATION OF THIS PRODUCT BE SURE THAT THE OPENING IS SQUARE.
- 2) BEFORE SECURING UNIT IN OPENING, CHECK WINDOW JAMB FOR SQUARE, PLUMB AND LEVEL, OR SASH MAY NOT OPERATE PROPERLY. MAKE SURE ALL REVEALS (GAPS BETWEEN JAMB AND SASH) ARE STRAIGHT AND EVEN.
- 3) SHIM JAMBS AS NECESSARY.
- 4) CHECK OPERATION OF SASH BEFORE FINAL APPLICATION OF INSIDE MOULDING. MAKE SURE ALL REVEALS ARE STRAIGHT AND EVEN.
NOTE: WE STRIVE TO ACHIEVE A CONSISTANT 3/16" REVEAL/GAP VERTICALLY AND TOP HORIZONTALLY.
- 5) APPLY OIL BASED PRIMER AND FINISH COATS IMMEDIATELY AFTER INSTALLATION. OVERLAP PAINT 1/16" ONTO GLASS BOTH INSIDE AND OUT. DO NOT PAINT WEATHERSTRIPPING. (WEATHERSTRIPPING IS REMOVEABLE.)

CAUTION: (1) TO ASSIST IN PROPER INSTALLATION, WINDOW MAY HAVE SHIMS INSTALLED BETWEEN SASH AND FRAME. IF POSSIBLE, DO NOT OPERATE UNTIL UNIT IS INSTALLED AND SHIMS HAVE BEEN REMOVED. (2) WOOD WINDOWS MAY BE DAMAGED BY EXPOSURE TO MOISTURE AND WEATHER IF NOT PAINTED PROMPTLY AND COMPLETELY.

BEFORE LEAVING JOB CHECK FOR PROPER OPERATION OF ALL WINDOW UNITS, SCREENS AND LOCKS.

SCREEN REMOVAL: GENTLY PULL UP ON SCREEN OVER WINDER. AFTER CLEARING WINDER, GENTLY PUSH DOWN ON SCREEN FRAME. TO REPLACE SCREEN, SIMPLY REVERSE REMOVAL STEPS.

REMOVAL OF SNAP-IN-GRILLS: TO REMOVE SNAP-IN-GRILLS GENTLY PULL OUT ON THE BOTTOM OF THE GRILL FRAME (NEVER PULL ON HORIZONTAL BARS AS DAMAGE MAY OCCUR).

LOCKS: WINDOW LOCKS ARE USED FOR BOTH SECURITY AND TO ENSURE A WEATHER-TIGHT SEAL. WIND WINDOW CLOSED TILL WINDOW IS SNUG (DO NOT OVERTIGHTEN WINDOWS) THEN PUSH LATCH LEVER DOWN TO SECURE AND TIGHTLY CLOSE UNIT.

IMPORTANT: RELEASE SASH LOCKS BEFORE ENGAGING WINDER – FAILURE TO DO SO MAY RESULT IN DAMAGE TO ROTO GEAR OPERATOR (WINDER), SASH OR JAMB. PERIODIC LUBRICATION OF WINDERS, LOCKS AND HINGES WILL EXTEND THE LIFE OF THE UNIT.

TO BE REMOVED BY HOMEOWNER ONLY!
