

Product Label - Wood & Clad Garden Windows

JT WINDOWS

➡ **IMPORTANT – PLEASE READ PRIOR TO INSTALLATION** ⬅

BEFORE PRODUCT INSTALLATION

- CHECK FOR CORRECT SIZE.
- CHECK FOR ANY FLAWS IN MATERIAL OR QUALITY OF WORKMANSHIP. IF ANY PROBLEMS ARISE, **DO NOT INSTALL OR PREFINISH. CALL AND RETURN PRODUCT TO SUPPLIER.**
- FAILURE TO DO SO WILL VOID ANY RETURN OR EXCHANGE.
- **INSTALLING OR PREFINISHING UNIT IMPLIES ACCEPTANCE.**

FINISHING

- HANDLE WITH CARE AT ALL TIMES. DO NOT EXPOSE TO WEATHER OR EXTREME TEMPERATURES PRIOR TO FINISHING.
 - REMOVE EXCESS GLAZING MATERIAL WITH A SHARP PUTTY OR X-ACTO KNIFE.
 - PRIME AND PAINT **ALL 6 SURFACES** WITH A MINIMUM OF AT LEAST 2 COATINGS EACH.
 - BE SURE TO OVERLAP PAINT 1/16" ONTO GLASS – REFER TO **JT FINISHING INSTRUCTIONS SHEET.**
- CAUTION: PRIMER IS NOT A FINISH COAT AND WILL NOT STAND UP TO WEATHER. IT IS PART OF THE PREPARATION PROCESS FOR FINISH COATING.**
- **STAINS AND CLEAR FINISHES, AND DARK COLORS, ARE NOT RECOMMENDED FOR EXTERIOR USAGE AS THEY WEATHER RAPIDLY AND PROVIDE POOR WOOD PROTECTION.**

CAUTION: USE EXTERIOR PAINTS FOR EXTERIOR PAINTING ONLY. PAINT MUST OVERLAP PUTTY OR WOOD STOP 1/16" ON TO GLASS TO FORM A PROPER SEAL AGAINST MOISTURE. DO NOT PAINT WEATHER STRIPPING.

WE DO NOT TAKE RESPONSIBILITY FOR THE STAINABILITY OF ANY PRODUCT YOU MAY PURCHASE.

AT JT WINDOWS INC. EXTREME CARE IS TAKEN IN PRODUCING HIGH QUALITY, WEATHER-TIGHT UNITS. ALL EXTERIOR JOINTS ARE TIGHTLY FIT AND FILLED AS NECESSARY TO ASSURE WEATHERABILITY. SINCE ALL WINDOWS LEAVE OUR FACTORY UNFINISHED, AND THE FINAL WEATHER COATINGS (FINISHING) ULTIMATELY REST IN THE HANDS OF OUR CUSTOMERS, **IT IS IMPOSSIBLE FOR THE FACTORY TO WARRANT AGAINST LEAKAGE.**

WE SUGGEST: AFTER THE FIRST 3-12 MONTHS INSPECT ALL WINDOW JOINTS FOR CRACKS OR SEPARATION IN FINISH. IF ANY ARE FOUND, LIGHTLY SAND AND FILL WITH CAULKING, THEN REPAINT.

SCREENS AND LOCKS

SCREEN REMOVAL: SIMPLY ROTATE SCREEN CLIPS AWAY FROM SCREEN FRAME AND REMOVE GENTLY.

WOOD GARDEN WINDOW LOCKS: TOP LOCKS ON WOOD GARDEN WINDOWS ARE USED TO SECURE SEAL ON TOP EDGES OF CASEMENTS AND CARE SHOULD BE TAKEN THAT CASEMENTS ARE UNLOCKED PRIOR TO OPENING WINDOWS AS BREAKAGE MAY OCCUR. FOR BOTH THE RIGHT AND LEFT SIDES, TURN LOCKS CLOCKWISE TO UNLOCK (AS VIEWED FROM THE INSIDE LOOKING OUT).

INSTALLATION INSTRUCTIONS

YOUR JT GARDEN WINDOW MAY BE INSTALLED IN BOTH NEW AND EXISTING CONSTRUCTION. THE WINDOW MOUNTS ON THE OUTSIDE AND CAN BE INSTALLED IN A STUCCO APPLICATION OR WOOD SIDING APPLICATION, MOUNTED DIRECTLY TO THE STUDS. BEST RESULTS ARE ACHIEVED BY REMOVING THE ENTIRE EXISTING WINDOW AND ATTACHING DIRECTLY TO THE STUDS. **DO NOT APPLY WINDOW OVER STUCCO, AS IT PROVIDES AN UNEVEN SURFACE.**

INSTALL DIRECTLY TO THE STUDS (FOLLOW AS NECESSARY)

- 1) REMOVE SLIDING BLOCKS AND NAILS FROM THE BOTTOM OF YOUR JT GARDEN WINDOW.
- 2) LOCATE AND TEMPORARILY SECURE A 2X4 ACROSS THE BOTTOM OF THE EXISTING OPENING TO AID IN SUPPORT DURING INSTALLATION. (ALLOW FOR FRAME HEIGHT, JAMB THICKNESS, OR TILE.)**
- 3) SET JT GARDEN WINDOW ON 2X4 AND CENTER OVER OPENING, ALLOWING FOR JAMBS, TILE, DRYWALL, ETC.
- 4) WHEN WINDOW IS PROPERLY CENTERED, SCRIBE AROUND PERIMETER OF MOUNTING FLANGE. TAKE WINDOW DOWN AND CUT AWAY STUCCO OR WOOD SIDING WITH A HAND RADIAL SAW. (USE MASONRY BLADE IF STUCCO.)
- 5) REMOVE CUT SIDING OR STUCCO. SET WINDOW INTO OPENING. INSTALL FLASHING ON ALL FOUR SIDES OF WINDOW OPENING, MAKING SURE IT IS TUCKED BEHIND EXISTING FLASHING.

NOTE: WE RECOMMEND A "Z" TYPE METAL FLASHING (NOT PROVIDED) ACROSS THE OUTSIDE TOP OF THE MOUNTING FLANGE (SEE "A").

- 6) USING 3" DRYWALL SCREWS, ATTACH WINDOW DIRECTLY TO STUDS.*** YOU CAN SCREW THROUGH EITHER MOUNTING FLANGE OR JAMB, IF ORDERED WITH JAMB. **CAUTION: DO NOT FORCE WINDOW ON TO UNEVEN SURFACES.**


- 7) CAULK OUTSIDE PERIMETER OF THE WINDOW. PAINT AND FINISH AS NECESSARY.

** **WHEN INSTALLING FOR TILE, LOCATE WINDOW SO THE TOP OF THE WINDER BODY HOUSING IS EQUAL TO OR ABOVE TILE LEVEL. ALLOW 1/4" GROUT SPACING WHEN TILING AROUND WINDER BODY HOUSING.**

*** **USE 3 SCREWS ON EACH SIDE AND 1-2 SCREWS ON THE TOP AND BOTTOM. INCREASE AS NECESSARY FOR LARGER WINDOWS. TOP SCREWS LOCATE UNDER GLASS.**

➡ **IMPORTANT** ⬅

- 1) CORBELS OR BOTTOM SUPPORTS ARE REQUIRED ON ALL JT PROJECTION WINDOWS. SUPPORTS MUST REACH TO OUTMOST PORTION OF WINDOW BODY (SEE B).
- 2) DO NOT ALLOW ROOF OF EXISTING BUILDING TO DRAIN DIRECTLY ONTO WINDOW. IF ROOF EAVES DO NOT EXTEND PAST TOP OF WINDOW USE A RAIN GUTTER OR DEFLECTION SHIELD TO RE-ROUTE DRAINAGE.



TO BE REMOVED BY HOMEOWNER ONLY!

www.jtwindows.com